

# 1002 Fitting Instructions

Thank you for your recent purchase. please see below a list of the contents. please note sometimes you may have received more than you require.



**28 x Wooden dowels**  
**20 x Screws**  
**20 x Silver fixings**  
**20 x plastic screw fixings**  
**20 x white plastic covers**  
**Top x 1 600 x 500 mm**  
**Short wooden supports x 2 (420 x 50 mm)**  
**Medium wooden supports x 2 (500 x 50 mm)**  
**Long legs x4 (680 x 50 mm)**



1, layout the top on a clean soft surface with the holes visible.

2, Using a soft rubber hammer knock in 12 of the plastic threads in the correct holes. Now insert the wooden dowels in the remaining holes.

**PLEASE NOTE: YOU DO NOT NEED TO USE ALL THE DOWELS!**



3, Locate the 4 long legs and insert a wooden dowel in to the end of each one, You will notice at the top of each leg there are four holes you will need to insert a wooden dowel in to the top one and the plastic thread and screw in to the other ( do this to all four legs )

5, Locate the four table top supports place them all with the holes facing up please put the silver fixing in to them and make sure you have the arrows facing out towards the smaller hole.



6, Join the legs to the four supports so when finished you will have a square base to support the table top.

7, carefully attach the legs and frame to the table top and secure by tightening silver fixings.

8, Carefully slide the glass into place.

## **IMPORTANT!**

**If you are placing a basin on the top of the unit then be very careful not to move the basin around as the ceramic underneath the basin will cause heavy marking to the table surface. When you have your basin in line simply mark the hole for cutting.**

**We recommend you place a soft sheet between the basin and the unit whilst measuring the hole.**